



Greenbriar Irrigation Timer Recommendations-

Please give this sheet to your contractor.

■ To program station times on your controller for the entire season:

1. Turn seasonal adjust dial to 100%

-This is the summertime setting

2. Rotary Sprinklers, front & rear yard:

- 30 minutes

3. Spray sprinklers, side yards with NO DRAINAGE ISSUES:

- 15 minutes

4. Spray sprinklers, side yards

Where there are DRAINAGE ISSUES:

- 3 to 4 minutes

5. Drip zones for established plantings:

- Leave them OFF till mid-summer

6. Turn your seasonal adjust DOWN to 50%

- this is the Springtime setting. It will automatically adjust EVERY station's time.

7. Please see the lawn cutting schedule for:

- recommended watering days and start times.

Leave **YOUR TIMER OFF** until Mother's Day

Please- have your rain sensor checked!

Coming Soon: Additional watering days recommended for
summer heat & drought conditions.